

# Polarization Extinction Ratio Meter-Manual

(all connector types and bare fiber input interface)



(Protected by pending patents)

DATASHEET

[Return to the Webpage](#)



## Applications

- Component Fabrication
- Quality Control
- Laboratory Use
- Connector Fabrication

## Features

- Low Cost
- Wide Wavelength
- Ease of Use
- Reliable
- Compact
- Bare Fiber Adaptor

The PERM-800 optical power meter is a cost effective solution to directly measure the output polarization extinction ratio from a fiber. It features unmatched low cost, large dynamic range, high resolution, and ease to use. The design adds a manual rotary polarizer to an optical power meter. As the polarizer rotates about 90 degrees, maximum and minimum intensity readings are obtained and the ratio is ER. The rotation is continuous, providing high resolution and accuracy. For the connector test, the polarizer rotary is pre-aligned to the key. The ease of operation has been proven in production and laboratory environments. **Some practice and patient is required to obtain peak reading.** The design accepts all types of fiber connectors as well as free space laser beam. The PERM-800 is ideal for PM fiber pigtailling of laser diodes, PM fiber patch cord manufacturing, PM fiber connectorization, PM fiber fusion splicing, PM fiber coil production, and quality assurance for fiber gyros.

One option is bare fiber can be conveniently insert into the meter, which matches our PM fusion splicer fiber holder. The PERM-800 is also an optical power meter.

## Specifications

Parameter	Min	Typical	Max	Unit
Wavelength Range	357		403	nm
	475		625	
	510		800	
	600		1000	
	900		1650	
	1700		2400	
Extinction Ratio Range		30		dB
Extinction Ratio Accuracy <sup>[1]</sup>		1		dB
Extinction Ratio Resolution		0.01		dB
Connector Angular Accuracy <sup>[2]</sup>		0.3		degree
Dynamic Range	-50		26	dBm
Input Optical Power	0.05		380	mW
Weight		0.49		Kg
Operating Temperature	-10		50	°C
Storage Temperature	-40		60	°C
Storage Humidity	< 90% RH non condensing			

### Notes:

[1]. ER is sensitive to fiber bending, temperature, and light source RE

[2]. For FC style connector with high tolerance keyway

**Special Note:** The rotation should be slow and smooth. Otherwise, the reading may jump due to electronic amplification processing algorithm.

**Note:** The specifications provided are for general applications with a cost-effective approach. If you need to narrow or expand the tolerance, coverage, limit, or qualifications, please [click this link](#):

**Legal notices:** All product information is believed to be accurate and is subject to change without notice. Information contained herein shall legally bind Agiltron only if it is specifically incorporated into the terms and conditions of a sales agreement. Some specific combinations of options may not be available. The user assumes all risks and liability whatsoever in connection with the use of a product or its application.

Rev 12/29/24

© Photonwares Corporation

**P** +1 781-935-1200

**E** [sales@photonwares.com](mailto:sales@photonwares.com)

**W** [www.agiltron.com](http://www.agiltron.com)

Information contained herein is deemed to be reliable and accurate as of the issue date. Photonwares reserves the right to change the design or specifications at any time without notice. Agiltron is a registered trademark of Photonwares Corporation in the U.S. and other countries.

# Polarization Extinction Ratio Meter-Manual

(all connector types and bare fiber input interface)



(Protected by pending patents)

## DATASHEET

### Dimensions

5 cm x 10 cm x 13 cm

\*Product dimensions may change without notice. This is sometimes required for non-standard specifications.

### Operation Instruction

1. Turn on the meter
2. Ignore the wavelength selection (affect the result small)
3. Plug the fiber into the input via a connector or bare fiber adaptor. The instrument accepts both FC and APC
4. Manually rotating the big round-shape polarizer rotator located on the top of the meter
5. Find the smallest value while slowly turning near the measurement valley and back and forth to stay at the lowest value. Then, push the dB button to zero the meter. The display shows 0 dB
6. Find the largest value while slowly turning near the peak and back and forth to choose the largest value. The value is the ER

### Accessories



Bare Fiber Adaptor

\$290

### Ordering Information

	800	<input type="checkbox"/>	<input type="checkbox"/>	2	1	<input type="checkbox"/>	<input type="checkbox"/>
Prefix	Type	Wavelength	Power Supply	Package	Configuration	Bare Fiber Adaptor	Connector Adaptor
PERM-		900-1650 = 1 1700-2400 = 2 600-1000 = 6 510-800 = 5 475-625 = 4 357-403 = 3 Special = 0	None = 0			None = 0 Yes = 1	FC/PC/APC = 1 LC/PC/APC = 4 Special = 0

“Special” – this category is to provide special performance beyond the parameters listed on the datasheet. NRE charge may be needed when this is selected.