(1x1, 1x2, 2x1 Standard Single and Dual Stage)

(Protected by U.S. patent 7,403,677B1 and pending patents)



Features

High speed
High repetition

High output voltage

Applications

Optical Switch


EO device driver

Wide input voltage range TTL/CMOS control Push-Pull output design Low power consumption Compact and low cost


DATASHEET



Return to the Webpage



The dual-stage configuration in NS switches increases the extinction ratio or cross-talk value.



Specifications

Parameter	Min	Typical	Max	Unit
Rise Time (Tr) [1]		85	100	ns
Fall Time (Tf) ^[2]		85	100	ns
Switch Speed (Rise) (Sr) [3]		250	260	ns
Switch Speed (Fall) (Sf) [4]		250	260	ns
Repetition Rate [5]	DC		300 [5]	kHz
Pulse Width	1.0			μs
Control Input (TTL pulse)	0		5	V
Power Consumption ^[5]			12	W
Power Current	0.08		1.0	Α
Power Supply		12		V
Operating Temperature	-5		70	°C
Storage Temperature	-40		80	°C
Electrical Connector				

Note:

- [1]: Optic Intensity Change from 10% to 90% intuits;
- [2]: Optic Intensity Change from 90% to 10% intuits;
- [3]: Switch Speed (Rise): Duration from begin of electronic signal to end of optic intensity change;
- [4]: Switch Speed (Fall): Duration from begin of electronic signal to end of optic intensity change.
- [5]: The maximum repeat rate may be reduced in \sim 50kHz when driving dual-stage NS switches
- [6]: Defined for SWDR with 1 NS switch.

Warning: Control Signal >5.5V Will Damage the Board

Warning: This is an OEM module designed for system integration. Do not touch the PCB by hand. The electrical static can kill the chips even without a power plug-in. Unpleasant electrical shock may also be felt. For laboratory use, please buy a Turnkey system.

Legal notices: All product information is believed to be accurate and is subject to change without notice. Information contained herein shall legally bind Agiltron only if it is specifically incorporated into the terms and conditions of a sales agreement. Some specific combinations of options may not be available. The user assumes all risks and liability whatsoever in connection with the use of a product or its application.

Rev 04/11/25

P +1 781-935-1200



w www.agiltron.com

© Photonwares Corporation



(1x1, 1x2, 2x1 Standard Single and Dual Stage)





CH1 2.00V

CH2 10.0mV

DATASHEET

Response Measurement






Mechanical Dimensions (Unit: mm)

M 100ns


22-Dec-23 10:36




Auto Coupling

CH2 / 16.0mV

299,996kHz






*Product dimensions may change without notice. This is sometimes required for non-standard specifications.

© Photonwares Corporation









(1x1, 1x2, 2x1 Standard Single and Dual Stage)



DATASHEET

DC Power Connection


Variation 1


P/N: SC1313-ND

Power Barrel Connector Jack 2.00mm ID (0.079"), 5.50mm OD (0.217") Through Hole, Right Angle


12V Wall Plug DC Power Supply Interface








Variation 2





Note: The DC Power Barrel Jack Connector can be replaced with a two-pin connector, available in two configurations: one with pins facing downward for direct PCB mounting and another for connection with a standard cable connector. This flexibility allows for integration into various system designs.



^{*}Product dimensions may change without notice. This is sometimes required for non-standard specifications.



(1x1, 1x2, 2x1 Standard Single and Dual Stage)




Ordering Information

			2	8	1	1	1	1
Prefix	Switch Type	Function	Latching	Repeat rate	Footprint	# of Switch	Control Mode	DC supply
SWDR-		1x1 = 1a 1x2, 2x1 = 2a 2x2 = 22 (single stage NS only) Special = 00	Non = 2	300kHz = 8	Standard = 1		TTL = 1	12VDC = 1

Note:

- ☐ This driver is intended mounted with specific switches, tuned, and tested prior to shipping. It is not designed to be sold separately.
- □ 5V DC supply may not be available for certain switch. Please have a consultant with the sales manager

Optical Power Handling vs Wavelength For Single-Mode Fibers



Operation Manual

- 1. Connect a control signal to the SMA connector on the PCB.
- 2. Attach the accompanied power supply (typically a wall-pluggable unit).
- 3. The device should then function properly.

Note: Do not alter device factory settings.





(1x1, 1x2, 2x1 Standard Single and Dual Stage)



TTL Driver Interface (Our Circuit Diagram)

